

Apple Studio Display

Before using your display, review the *Getting Started with Apple Studio Display* guide at support.apple.com/guide/studio-display. Retain documentation for future reference.

Safety and Handling

See "Safety and Handling" in the *Getting Started with Apple Studio Display* guide.

Safety Information

Failure to follow the safety instructions below could result in fire, electric shock, or other injuries, or damage to your Studio Display or other property. Read all safety information below before using your Studio Display.

Handling

Set up your Studio Display on a hard, stable work surface that allows for adequate air circulation under and around it. Never push objects into the ventilation openings. Your Studio Display can be damaged if dropped, burned, punctured, or crushed, or if it comes in contact with liquids, oils, and lotions. Don't use a damaged Studio Display, such as one with a cracked screen, as it may cause injury.

Mounting Solutions

Caution: Keep hands and fingers away from the moving parts of the stand to avoid pinching.

If you're using a Studio Display with a built-in VESA mount adapter, read the *Studio Display with VESA mount adapter Setup Guide* before you begin. Also read all the installation instructions and safety information that came with your VESA-compliant 100 x 100 mm mounting solution before attaching it to the VESA mount adapter.

Important: Agency Compliance Information and the serial number are marked on the bottom of the stand of your Studio Display or the side of your built-in VESA mount adapter and may be obscured when using the VESA mount adapter with some mounting solutions.

Power

Unplug the power cord (by pulling the plug, not the cord) and disconnect all cables if any of the following conditions exists:

- The power cord or plug becomes frayed or otherwise damaged.
- You spill something onto the display.
- Your Studio Display is exposed to rain or excess moisture.
- Your Studio Display has been dropped, or the case has been damaged.
- You suspect that your Studio Display needs service or repair.
- You want to clean your Studio Display.

The only way to turn off power completely is to unplug the power cord from the wall outlet. Make sure the power cord is within easy reach so that you can unplug your Studio Display when you need to.

Your AC cord has a three-wire grounding plug (a plug that has a grounding pin). This plug fits only a grounded AC outlet. If you're unable to insert the plug into an outlet because the outlet isn't grounded, contact a licensed electrician to replace the outlet with a properly grounded one. Do not defeat the purpose of the grounding pin.

Precautions

A display may fall, causing serious personal injury or death. Many injuries, particularly to children, can be avoided by taking simple precautions such as:

- Follow the instructions by the manufacturer when using a stand or adapter for mounting the display.
- Always use furniture that can safely support your Studio Display.
- Always ensure your Studio Display is not overhanging the edge of supporting furniture.
- Always educate children about the dangers of climbing on furniture to reach your Studio Display.
- Always route cords and cables connected to your Studio Display so that they cannot be tripped over, pulled over, or grabbed.
- Always keep hands and fingers away from the moving parts of the stand to avoid being pinched.

- Never place your Studio Display in an unstable location.
- Never place your Studio Display on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and the Studio Display to a suitable support.
- Never place your Studio Display on cloth or other materials that may be located between the Studio Display and supporting furniture.
- Never place items on or around your Studio Display that might tempt children to climb on top of the display or the furniture on which it's placed.

Ventilation

Don't block the bottom or top ventilation opening of your Studio Display. Don't place the Studio Display where ventilation is restricted (for example, in a cabinet).

Temperature

Don't expose the Studio Display to excessive temperatures (ambient operating temperature should be 50° to 95° F or 10° to 35° C), moisture, or humidity. The Studio Display is not recommended for outside use.

Clean the Display

If your Studio Display has nano-texture glass, clean it only using the included polishing cloth. If your Studio Display has standard glass, you can clean it using a dampened microfiber cloth. Do not use furniture cleaner, glass cleaner, disinfecting wipes, hand sanitizer, or any other type of solvent.

FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and

used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this product not authorized by Apple could void the electromagnetic compatibility (EMC) and wireless compliance and negate your authority to operate the product.

This product has demonstrated EMC compliance under conditions that included the use of compliant peripheral devices and shielded cables between system components. It is important that you use compliant peripheral devices and shielded cables between system components to reduce the possibility of causing interference to radios, televisions, and other electronic devices.

Responsible party (contact for FCC matters only):

Apple Inc.
One Apple Park Way, MS 911-AHW
Cupertino, CA 95014
USA
apple.com/contact

ISED Canada Compliance

CAN ICES-3 (B)/NMB-3(B)

EU / UK Compliance

Complies with the Low Voltage Directive 2014/35/EU, EMC Directive 2014/30/EU, Safety Regulation 2016, and Electromagnetic Compatibility Regulations 2016.

Apple's EU representative is Apple Distribution International Ltd., Hollyhill Industrial Estate, Cork, Ireland. Apple's UK representative is Apple UK Ltd., 2 Furzground Way, Stockley Park, Middlesex, UB11 1BB.



ENERGY STAR® Compliance



As an ENERGY STAR partner, Apple has determined that standard configurations of this product meet the ENERGY STAR guidelines for energy efficiency. The ENERGY STAR program is a partnership with electronic equipment manufacturers to promote energy-efficient products. Reducing energy consumption of products saves money and helps conserve valuable resources.

This display is shipped with power management enabled, which allows the display to save power by decreasing luminance when used in a room with low ambient lighting. This automatic brightness control feature is enabled as a default setting in Displays preferences. To adjust your display luminance manually, use the display brightness keys on your keyboard or the brightness adjustment slider in Displays preferences.

For more information about ENERGY STAR, visit energystar.gov.

Disposal and Recycling Information



The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

Software License Agreement

Use of Studio Display constitutes acceptance of the Apple and third-party software license terms found at apple.com/legal/sla.

Apple One-Year Limited Warranty Summary

Apple warrants the included hardware product and accessories against defects in materials and workmanship for one year from the date of original retail purchase. Apple does not warrant against normal wear and tear, nor damage caused by accident or abuse. To obtain service, call Apple or visit an Apple Store or an Apple Authorized Service Provider—available service options are dependent on the country in which service is requested and may be restricted to the original country of sale. Call charges and international shipping charges may apply, depending on the location. Subject to the full terms and detailed information on obtaining service available at apple.com/legal/warranty and support.apple.com, if you submit a valid claim under this warranty, Apple will either repair, replace, or refund your hardware device at its own discretion. Warranty benefits are in addition to rights provided under local consumer laws. You may be required to furnish proof of purchase details when making a claim under this warranty.

For Australian consumers: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Apple Pty Ltd, PO Box A2629, Sydney South NSW 1235. Tel: 133-622.

© 2022 Apple Inc. All rights reserved. Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries and regions. Apple Studio Display is a trademark of Apple Inc. Apple Store is a service mark of Apple Inc., registered in the U.S. and other countries and regions. ENERGY STAR and the ENERGY STAR mark are registered trademarks owned by the U.S. Environmental Protection Agency. Printed in XXXX. 034-05042-B