


5.

FN + 9 (= CUSTOM MODE 1

FN + 0) = CUSTOM MODE 2




6.

1 FN + END

2 [Light indicator sequence]

3 [Hand pointing to keyboard]

4 FN + END



• CLEVER GAMING



GAMING X Trust.

CALLAZ USER GUIDE MECHANICAL TKL GAMING KEYBOARD

Bedienungsanleitung | Mode d'emploi | Gebruikershandleiding | Manuale utente | Manual del usuario | Guia do utilizador | Brukerveiledning | Bruksanvisning | Käyttöopas | Brugsvejledning | Instrukcja obsługi | Návod k použití | Návod na používanie | Használati útmutató | Manual de utilizare | Ръководство за потребителя | Εγχειρίδιο χρήσης | Kullanıcı kılavuzu | Руководство пользователя | Uporabniški priročnik | Korisnički priručnik | Guia do usuário | Посібник користувача | مدد دسترس آسان

FAQ WWW.TRUST.COM/24404/FAQ Trust International BV - Laan van Barcelona 600 - 3317DD, Dordrecht, The Netherlands ©2023 Trust All rights reserved.

1.




2.

- FN + F1 = Copy
- FN + F2 = Search
- FN + F3 = Calendar
- FN + F4 = Music
- FN + F5 = Previous
- FN + F6 = Next
- FN + F7 = Play/Pause
- FN + F8 = Stop
- FN + F9 = Mute
- FN + F10 = Unmute
- FN + F11 = Volume Up



3.

- FN + Up Arrow OR Down Arrow = Brightness Control
- FN + Left Arrow OR Right Arrow = Standby/Power



4.

