



RAZER HYPERPOLLING WIRELESS DONGLE


MASTER GUIDE

CONTENTS

1. WHAT'S INSIDE	2
2. WHAT'S NEEDED	2
3. LET'S GET YOU COVERED	3
4. SETTING UP YOUR RAZER HYPERPOLLING WIRELESS DONGLE.....	3
5. CONFIGURING YOUR RAZER HYPERPOLLING WIRELESS DONGLE VIA RAZER SYNAPSE	4
6. SAFETY AND MAINTENANCE	10
7. LEGALESE.....	11

1. WHAT'S INSIDE

- Razer HyperPolling Wireless Dongle



- A.** Type C port
- B.** Indicator LED*

**Indicator display can be customized to show connection status (default) or battery status with a low-battery warning using the Razer Synapse app.*

- Important product information guide

2. WHAT'S NEEDED

PRODUCT REQUIREMENTS

- Type A port
- Type A to Type C cable (included with your Razer mouse)
- Razer HyperPolling Wireless supported mouse**

RAZER SYNAPSE REQUIREMENTS


- Windows® 10 64-bit (or higher)
- Internet connection for software installation

***For an updated list of compatible Razer mice, visit rzd.to/hyperpolling*

3. LET'S GET YOU COVERED





Register your product and score exclusive benefits
razerid.razer.com/warranty



*Your product's serial number
can be found here.*

4. SETTING UP YOUR RAZER HYPERPOLLING WIRELESS DONGLE



1. Install Razer Synapse when prompted or download the installer from razer.com/synapse and update it to its latest version.
2. Set device pairing via Razer Synapse pairing interface.

5. CONFIGURING YOUR RAZER HYPERPOLLING WIRELESS DONGLE VIA RAZER SYNAPSE


i *Internet connection is required for installation, updates, and cloud-based features. Registering for a Razer ID account is recommended but optional. All listed features are subject to change based on the current software version, the connected device(s), and supported apps and software.*

SYNAPSE TAB

The Synapse tab is your default tab when you first launch Razer Synapse. This tab allows you to navigate the Dashboard subtab.


Dashboard

The Dashboard subtab is an overview of your Razer Synapse, where you can access all your Razer devices, modules, and online services.



Modules


The Modules subtab displays all installed and available modules for installation.



Global Shortcuts

Bind operations or Razer Synapse functions to custom key-combinations from any Razer Synapse-enabled device inputs, which apply across all device profiles.

! *Only Razer Synapse-enabled device inputs will be recognized.*




ACCESSORY TAB

The Accessory tab is the main tab for the Razer HyperPolling Wireless dongle. From here, you'd be able to pair the wireless dongle with your compatible Razer mouse and customize what the indicator LED of the wireless dongle shows.

Pairing


Use the Pairing tab to pair (or unpair) the wireless dongle with your compatible Razer mouse. To pair your compatible Razer mouse, launch the Pairing Utility and follow the on-screen instructions.



Upon pairing your wireless dongle with your Razer mouse, click on **Configure Polling Rate** to access the new polling rate options available in your Razer mouse. Alternatively, you can directly access your Razer mouse's polling rate from its Performance subtab.


Lighting

Customize the wireless dongle to either indicate your Razer mouse's connection or battery status or only indicate battery warnings when your Razer mouse needs charging.



SETTINGS WINDOW

The Settings window, accessible by clicking the (⚙️) button on Razer Synapse, enables you to configure the startup behavior and display language of Razer Synapse, view the master guides of each connected Razer device or perform a factory reset on any connected Razer device.



General tab

The General tab lets you change the software's display language, startup behavior, theme, and on-screen notifications display. You may also manually sync your profiles to the cloud (↻) or view the master guide of all connected Razer devices and installed modules.

Dashboard tab

Use the Dashboard tab to customize which Razer device recommendations based on your setup, and the games you play will appear on the Dashboard.

Reset tab

The Reset tab allows you to perform a factory reset on all connected Razer devices with on-board memory and/or reset Razer Synapse tutorials to acquaint yourself again with Razer Synapse's new features on its next launch.



All profiles stored on the selected device's on-board memory will be erased when you reset a Razer device.

About tab

The About tab displays brief software information and copyright statement, and provides relevant links for its terms of use. You may also use this tab to check for software updates, or as quick access to Razer's social communities.

6. SAFETY AND MAINTENANCE

SAFETY GUIDELINES

To achieve maximum safety while using your Razer HyperPolling Wireless Dongle, we suggest that you adopt the following guidelines:

- Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for support.
- Don't take apart the device, and don't attempt to operate it under abnormal current loads. Doing so will void your warranty.
- Don't use or place the device near water, moisture, or other wet surfaces.
- Don't use or place the device near heat, naked flame, or other hot surfaces such as radiators, stoves, fireplaces, and candles.
- The device should only be used with compatible Razer wireless charging-enabled mice. Razer shall not be responsible for any damages incurred to any device when using the Razer HyperPolling Wireless Dongle.
- Keep the device away from liquid, humidity, or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug the device to let the temperature stabilize to an optimal level.

7. LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2022 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", and "Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. or affiliated companies in the United States and other countries. All other trademarks are the property of their respective owners.

Windows and the Windows logo are trademarks or registered trademarks of the Microsoft group of companies.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer HyperPolling Wireless Dongle (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit razer.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.