

<https://youtu.be/TRJ4vvSf8YI>

This video is a step-by-step process on how to enable gaming mode on a Razer keyboard or laptop.

Gaming mode is a feature that prevents accidental usage of specific keys when pressed unintentionally. You can also customize which keys to disable when activated such as Alt + Tab and Alt + F4, except Windows key which is persistently disabled.

Enabling gaming mode can be done via Razer Synapse for both Razer laptops and keyboards, however, only keyboards have the option to enable gaming mode just by pressing certain key combinations.

Do note that not all Razer keyboard models have the gaming mode feature.

In this video, you will learn how to activate gaming mode on your Razer keyboard or laptop.

Let's get started.

On your Razer Blade, open Razer Synapse 3 and go to "SYSTEM" > "CUSTOMIZE."

Next, select "Always on" or "Enable in-game" from the dropdown list under "GAMING MODE."

Gaming mode on your Razer Blade should now be enabled.

To enable gaming mode on your Razer keyboard via Razer Synapse, open Razer Synapse 3 and go to "KEYBOARD" > "CUSTOMIZE."

Next, select "Always on" or "Enable in-game" from the dropdown list under "GAMING MODE."

To enable gaming mode using key combinations:

Press fn + F10 for full-sized keyboards including tenkeyless, or;

Press fn + U for mini or 60% and 65% smaller keyboards.

Gaming mode on your Razer keyboard should now be enabled.

Congratulations! You have successfully enabled gaming mode on your Razer keyboard or laptop.