






CARVAAN TM 2.0

USER MANUAL HINDI | हिंदी

BUTTONS & PORTS ON SAREGAMA CARVAAN 2.0







Full battery charge time: 6-7 hours; Battery usage: Approximately 5 hours once the battery is fully charged

The battery charging indicator will display:

- a. Red light when Carvaan is being charged
- b. Green light when Carvaan is fully charged

To choose a mode, press the corresponding mode button on the unit/ remote

- 1. **SAREGAMA:** 5000 pre-loaded evergreen songs categorized into Artistes, Specials, Geetmala & Wi-Fi. This mode is the default mode on first power on/reset
- 2. **USB*** / **AUX IN:** Plug in a USB into the USB port on Carvaan to enjoy your personal collection of songs. You can also connect an Aux cable in the Aux IN port on the back panel of Carvaan to play songs from your phone/tablet. Press the mode button to switch between USB and Aux In
- 3. **FM/AM****: Listen to local FM/AM stations. Press the mode button to switch between FM and AM

FM frequency: 87.5 to 108 MHZ AM frequency: 520 to 1620 KHZ

Note: We recommend that you do not put the unit on charge while listening to FM/AM as it will interrupt the signal


4. **BLUETOOTH*****: Pair your mobile phone / tablet with Carvaan. Enjoy songs stored on your personal device on Carvaan speakers

^{*}support for USB 2.0

^{**}AM station will play as per broadcast timings

^{***}support for BT version 4.1





SAREGAMA CARVAAN APP

Download the 'Saregama Carvaan' app from the Apple / Android store to enjoy a host of free and subscription based services.

Free services – Use the app to find a song, create playlists to playout on your Carvaan unit.

Note: To use the app, press the 'Saregama mode' button on Carvaan. Connect the app & Carvaan using Bluetooth on your phone/tablet.

Subscription services - Subscribe to the app and listen to the songs on your phone/tablet without being connected to the Carvaan unit

Refer to the enclosed insert for steps on how to connect the app and Carvaan unit.





Choose a category in Saregama Mode. Each category under Saregama mode has multiple genres in it. To change genres in any of the categories, press the respective category button for 3-4 seconds.

1. Artistes: 65+ music stations dedicated to legends like Lata Mangeshkar, Kishore Kumar, Asha Bhosle, Mohd. Rafi, R.D. Burman, Gulzar, Rishi Kapoor, Amitabh Bachchan, Noor Jehan, Mukesh, Nargis, Rekha etc.

Genres like actors, singers, lyricists etc.

- 2. Specials: 15+ music stations dedicated to Specials like Romance, Ghazal, Gurbani, Bhakti, Kapoors, Sad, Songs with Dialogues, Hindustani Instrumental, Favourites etc. Genres like moods, bollywood etc.
- 3. Geetmala: 50 years of Ameen Sayani's Geetmala spanning across 50 music stations.

 Eras like 50's. 60's. 70's etc.
- **4. Wi-Fi:** Many Wi-Fi based stations across genres like devotional, health & wellness, kids, entertainment, and much more. To enjoy Wi-Fi based stations connect Carvaan 2.0 to a Wi-Fi network using the 'Saregama Carvaan' app.

Go to page 4 for details on how to connect the Carvaan unit to Wi-Fi.




Voltage: 110-240V

Frequency: 50/60 Hz for input and 5V 1A for output




External Antenna:

Insert the antenna into the AUX IN port for improved reception of local FM stations



Choose your preferred category in Saregama mode



SAFETY HANDLING

1. CARE FOR PRODUCT

- a. Keep Carvaan away from dust and excessive heat (heat registers, stoves etc.)
- b. Prevent spillage of water or any other liquid as this can cause failure of Carvaan or could prove to be a potential fire hazard
- c. Clean the unit with a dry cloth only
- d. Do not walk on or pinch the power cord close to the plug
- e. Do not immerse Carvaan or the remote into water
- f. Remove the remote battery when it is not used for longer duration
- g. Do not mix different brands or types of batteries in the remote

2. CARE FOR BATTERY

- a. Do not expose the battery to heat sources greater than 60°C
- b. Recycle or dispose the battery when essential. Please ensure proper battery handling and disposal methods

To replace the remote control battery:

- 1. Open the battery compartment
- 2. Insert a fresh CR2025 battery with the correct polarity (-/+)
- 3. Close the battery compartment
- 4. Discard the used battery

IMPORTANT LINKS

Station List & Song List: www.saregama.com/carvaan/wifi/songlist

Detailed Warranty:

www.saregama.com/carvaan/wifi/warranty

Download the "Saregama Carvaan" app from the **Apple**/ **Android** store.





- c. Do not subject the battery pack to a mechanical shock
- d. In the event of a battery leak, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with water and seek medical advice
- e. For prolonging battery life, avoid discharging the battery completely

3. OTHERS

- a. Use attachments/accessories as specified by the manufacturer
- b. To register a complaint or a service request, please send an email to help@saregama.com

Waste electrical products should not be disposed of with household waste. Please follow disposal and recycling instructions issued by the concerned local authority.

WARRANTY OVERVIEW

1-year warranty on all parts of Saregama Carvaan 2.0 (excluding accessories). This includes replacement of damaged units

The warranty does not cover the following:

- Liability for loss of data/content loaded in the product due to misuse or tampering by the customer
- · Functionality of the Product(s)
- Wear and tear of the memory card, speaker, battery and display panel if the product is used in commercial, business, industrial, educational or rental applications
- Damage caused due to act of God & force majeure events including but not limited to fire or water damage, electrical disturbances etc.

To register a complaint or a service request, please send an email to help@saregama.com

WARRANTY CARD

Customer's Name: Customer's Address:
Product Serial No.:
Date of Purchase:
Expiry Date:
I accept the terms and conditions of the warranty.
Retailer's Name:
Retailer's Signature/Seal:
Customer's Signature

WARRANTY TERMS

Warranty is provided only on Product(s) which is purchased from Saregama, Saregama Authorized Dealer, Authorized Reseller or Authorized Online Resellers. 1-year warranty will be provided on the Product(s).

In order to claim the Warranty Customer will have to mail their request to help@saregama.com

The Customer will receive as reply to his/ her email an address on which said Customer may send the defective unit of the Product ("said address").

The defective unit of the Product and Accessories must be sent to the said address (with the original packaging when purchased or similar packaging) at the cost of the Customer. Once the said defective unit of the Product and Accessories is received at the said address, Saregama will dispatch a fresh unit of the Product and Accessories to Customer's address. In the event on receipt, Saregama finds that the allegedly defective unit of Product does not have any defects, Saregama will dispatch the same unit of the Product and Accessories received from Customer, back to the Customer's address.

In order to avail the Warranty, customer will have to provide the invoice of the unit of the Product purchased by customer to Saregama, either by dispatching it to Saregama along with the defective unit of the product or by emailing to Saregama at the email address provided for the same purpose a scanned copy of the said invoice.

The replaced unit of the Product and Accessories shall become the property of Saregama.

CARVAAN UNIT AND Wi-Fi CONNECTIVITY

To enjoy Wi-Fi based stations the Carvaan unit needs to be connected to Wi-Fi. (ensure the Wi-Fi speed is good to enjoy an uninterrupted experience)

SET UP PROCESS:

On Carvaan

 On your Carvaan unit, press the 'Saregama' button, followed by 'Wi-Fi' category button

On your mobile phone

- Turn on the Bluetooth of your mobile phone / handset
- Download the 'Saregama Carvaan' app
- Open the app
- Choose 'Play on Carvaan'
- Next, select Carvaan 2.0 from the list of available devices
- Tap on the menu on the top left of your screen & select "Connect to Wi-Fi"
- Choose a Wi-Fi network & enter the password; the app will remember your Wi-Fi password

To change the network, go to "Connect to Wi-Fi" page on the app & select the preferred network.

Note: Wi-Fi charges will be as per your Wi-Fi service provider